CD CARE

CD-320

WET TYPE COMPACT DISC RADIAL CLEANER

WHY DO CD'S NEED TO BE CLEANED?

Everyday handling of CD's can leave fingerprints and dirt on discs, resulting in skipping, mis-tracking and sound distortion during play.

Periodic cleaning can prolong CD life by preventing scratches and restore performance impaired by contaminated disc surfaces.

MAXELL CD-320 FEATURES

- Radial cleaning action from the disc's center axis to its outer perimeter provides the ideal method of CD protection.
- Natural chamois pad for superior CD protection.
- Non-abrasive cleaning formula leaves no residue.

INSTRUCTIONS



STEP 1



STEP 2

STEP 3

Step 1. Insert Compact Disc into Radial Cleaner with label side down.
Step 2. Holding bottle 4″ from surface of CD, apply one even spray of cleaner solution. **NOTE**: Never apply cleaner solution to label side of CD's.
Step 3. Close lid of cleaner and rotate crank clockwise for 20 turns to insure proper cleaning of the entire disc area.
NOTE: Be careful not to scratch either side of disc. Use only recommended CD cleaning fluids. Always store the disc in the original box when not in use. Be sure cleaning fluid has evaporate priior to placing disc in player.

CAUTION: CLEANING SOLUTION CONTAINS ALCOHOL. KEEP OUT OF REACH OF CHILDREN.

MAXELL WARRANTY

Maxell warrants this product to be free from manufacturing defects in materials and workmanship for a period of 90 days from the date of original purchase. Any product found to be defective will be replaced at no charge, during the warranty period, if it is returned with proof of purchase to Maxell Corp. of America, 1400 Parker Road, Conyers, GA 30207. MANUFACTURER, DISTRIBUTOR AND SELLER SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR COMMERCIAL DAMAGES. SOME STATES DO NOT ALLOW A LIMITATION WITH RESPECT TO CONSEQUENTIAL DAMAGES. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

maxell
Maxell Corp. of America
22-08 Route 208
Fair Lawn, NJ 07410

Printed and Packaged in the U.S.A.

MADE IN CHINA



0 25215 19002 5